


INSTRUCTION MANUAL 86298

Features

- 1. 13 digits display: Hour, Minute Second, Month, date
 Day of week
- 2. Auto calendar from 2015 to 2065
- 3. Chronograph with 1/100 second
- 4. daily alarm and hourly chime
- 5. Dual time zone
- 6. Count down timer with maximum of 23 hours 59mins and 59secs
- 7. 12 /24 hour format
- 8. animation dots second display
- 9. EL back


Mode Transition Diagram





If the watch is not under time mode, the display will return to time mode when button S3 is pressed after press either button S1 or S2.

CARE OF YOUR WATCH


- This watch contains electronic components.
 Never attempt to open the case or remove the back cover.
- 2.Do not operate push buttons below the surface of the water while swimming or diving.
- Should water or condensation appear in the watch, have the watch checked immediately.
 Corrosion of electronic parts can occur inside the case.
- 4. Avoid severe impact. The watch is designed to withstand impact under normal use. It is inadvisable to subject it to severe impact or rough usage.
- 5. Avoid exposing the watch to extreme temperature.
- Clean the watch with soft cloth and clean water only. Avoid using chemicals.
- 7.Keep your watch away from the conditions of strong electric field and static electricity.








Press S4 to exist the time setting mode





and 59secs

