

NOWLEY

INSTRUCTION MANUAL 85528

LIGHT (A Key) ——— (D Key) START
MODE (B Key) ——— (C Key) RESET



A. Features


- 13 Digits LCD Display, Display Hour, Minute, Second, Month, Day and Week
- Daily Alarm and Chime hourly
- 12 / 24H format selectable, Auto Calendar
- 1/100 second Chronograph with split functions

1

2

- Timer
- Dual Time
- key tone
- EL backlight

B. Operational Manual



3

1. At any state ,press A key EL backlight for 3s .

2. Real Time

- Time Setting
 - a). Press and hold C key for 2s to time setting state and "Second" flashing, press D key to zero; Press B key to select item as following sequence : Second → Minute → Hour → 12/24H format → Month → Day → Week
 - b). Press D key to adjust the flashing item.
 - c). Press C key to return to Real Time Mode.
 - d). Press D key while the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes . In the range of 00 to 59 resets them to 00

4

and adds to the minutes. In the range of 00 to 29, the minutes are unchanged.

3. Daily Alarm

- Turn On / Off Alarm and Chime
Press D key to turn on/off Alarm ("ALM") or Chime ("CHI") .
- Alarm setting
Press and hold C key for 2s to select "Hour" setting ; Press B key to select "Minute" setting; Press D key to adjust the flashing item.
- There will be 20s alert when alarm time is over.

4. Chronograph

- Press D key to Start/Stop running ;
- When stop ,press C key to zero .
- When running ,press C key to split Counting. Then press D key to exit split count, and stop counting; When exit split count, press C key to zero.
- When running ,press B key to return to Real Time mode ,and it running at back .

5. Timer mode

- The display range of the timer is 23hour 59minute 59 second.
- Timer alarm sounds for about 10 seconds when counting down to 0:00:00., The timer is automatically reset to its starting value after the alarm stops.
- Timer Time setting

5

6

Press and hold C key for 2s to time setting state and "Hour" flashing , Press B key to select "Hour" or "Minute" setting , Press D key to adjust the flashing item, Press C key to complete setting.

- Timer operation
Press D key to Start/Stop counting ; Press C key to starting value when stop counting.

6. Dual Time

- Dual Time setting
In the Dual Time mode , Press and hold C key for 2s to select "Minute" setting, Press B key to select "Hour" setting, Press D key to adjust the flashing item, Press C key again to finish setting , and return to Dual Time displaying mode .

7

8