

Compatible system and requirement Android 4.4 or above	The bracelet function specifications Time: Time, date, remaining power are shown on the watch face. (Once smart band connected to the device, time will be synchronized with device time. The time cannot be set on the smart band). Status mode: Record user steps daily, walking distance, calories consumption.	Others: Charging alert, alarm reminder, sedentary reminder, incoming call display, shake to take picture, system update, WeChat/QQ/Text message notification	Basic parameters OLED screen size Bluetooth version Waterproof	0.96" inch BT4.0 IP67
Please charge the smart band fully before first use. Charge 1–1.5 hours if the smart band cannot turn on. The smart band are unable to use while in charging mode.	Heart rate measurement: measure heart rate hourly, or measure heart rate manually. Press and hold to enter into heart rate measurement interface.	① Please ensure the bluetooth is ON and the system of mobile phone is Android 4.4 or	Battery type	Polymer lithium battery
Tft display screen Sensnor light Sensnor light Lip charging Clip charging Lip charging O Connection Instruction Download the App Method1: Scan the code below to download the APP. Method2: Please ensure the bluetooth is on, and open Wearthr [*] Click the selection of link to bracelet, find the dovice name in the list and dick it. Then onter the Image: Click the selection of link to bracelet, find the dovice name in the list and dick. It. Then onter the	Blood pressure measurement: measure blood pressure hourly, or measure blood pressure manually. Press and hold to enter into blood pressure measurement interface.	above and IOS 8.4 or above. ② If if it still unable to connect, enter the phone settings → Application Management→ Authorization Management→ Application Rights Management→Find application [WearFit]→ Allow all permissions as "allowed"→ Enter the phone settings and select GPS location and turn on GPS function, →Pestarit the phone—Try to connect. ③ Please ensure bracelet is fully charged. Do feel free to contact us if it can t work normally with blenty power.	Battery capacity Charging time Strap size	90mAh 1.5-2 hours 255mm*20mm*2.2mm
	 Blood oxygen measurement: measure blood oxygen hourly, or measure blood oxygen manually. Press and hold to enter into blood oxygen measurement interface. Sport mode: Press and hold on the sport mode interface to enter the sports selection page. There are five different sport modes for selection. Running indoor, running outdoor, cycling, sport waking, and exercise modes. Press and hold to return. 		Charge Method Packing	Clip charging Wristband, Charging Clip, User Manual
		2. The APP shows no connection after bound with bracelet, or it is connected but the power is 0%? In this case, the App is not bound with bracelet successfully, please rebind.	 Remark I, If there is a product quality problem or the use of products is not clear, please contact our store by direct mail, we will deal with it quickly. The measurement results of this product are for reference only, not for any medical purpose and basis. Please follow the doctor's instructions and do not rely on the measurement results for self diagnosis and treatment. The waterproof grade is IP67, which can be used for daily life waterproof. But the bracelet can not be used for diving and put under water for long time. In addition, this 	
	Weather: The real-time weather condition will be synchronised with your device data and shown on the time display interface. The smart band needs to be connected to the APP and the device GPS function needs to turn on .	 Can't connect the device with APP? Pull down and refresh main interface, it will manually to synchronize the data, then it can display data in the APP. Auto-sync data will only be synchronized at first binding. Then it will automatic synchronize of data hourly. In addition, don t forget to open hourly measurement. Otherwise histogram hasn t any data. Pull-down and refresh APP, the data is not loaded? App settings—Restore the factory settings—Click restore factory settings—Turn off the brackelt -Measure hourds out. 		
	More: Do not disturb (Press and hold to cancel or turn on vibration), music (press and the other music control panel, press to switch, press and hold to contrinu), timer I (press and hold to contrinu), timer I (press and hold to contrinu), timer I (press and hold to contrinu), timer I second to enter timer, press to start), find my phone (press for 5 I second to enter phone finding modepress to start). Find my phone according to the I ringtone and vibrationpress to stop). Please make sure the phone and the smart I band are connected and within operating range.			
		5. The bracelet time is not synchronized after connecting with the phone? In Mobile phone settings—Application management/rights management—Open permissions of		
the device name in the list and click it. Then enter the Scan GR code downbad	Settings: Turn off (press and hold to turn off, press to switch), reset (press and hold to check the firmware version, MAC address, press and hold to return or return after five second)	APP—Reconnect the bracelet—Pull down and refresh it at main interface of the APP.		